


























JOHN DEERE SERVICE AND PARTS MANUALS






<p>0001</p>	<p>438</p>	<p>Technical Manual 300 Series OEM Engines TM1190, December 1984</p>	
<p>0002</p>	<p>182</p>	<p>Operators Manual 4.5 and 6.8 L 4045 and 6068 OEM OMRG37407 May 2006</p>	
<p>0003</p>	<p>761</p>	<p>Technical Manual PowerTech 8.1 L CTM255 May 2003</p>	
<p>0004</p>	<p>718</p>	<p>Component Technical Manual 220 Series CTM3 August 1993</p>	
<p>0005</p>	<p>218</p>	<p>Operators Manual PowerTech 10.5/12.5L OMRG29968 March 2006</p>	







<p>0006</p>	<p>198</p>	<p>Operation and Service Manual PowerTech 8.1L 6081 OEM OMRG24828 December 2000</p>	
<p>0007</p>	<p>209</p>	<p>Operators Manual PowerTech 4.5L & 6.8 L OMRG33324 April 2003</p>	
<p>0008</p>	<p>119</p>	<p>Operation and Service Manual Series 300,3029,4039,4045,6059,6068 OEM OMRG18293 C3 March 1993</p>	
<p>0009</p>	<p>132</p>	<p>Operators and Maintenance Manual PowerTech 4.5L & 6.8 L 4045 and 6068 OEM OMRG25204 May 1996</p>	
<p>0010</p>	<p>152</p>	<p>Use and Maintenance Manual PowerTech 2.9L 3029 OEM OMRG27897 January 2001</p>	





0011	150	Use and Maintenance Manual PowerTech 4.5L & 6.8L 4045 and 6068 OEM OMRG25204 January 1999	
0012	122	Operators Manual Series 300,3164,3179,4219 4239,4276,6329,6359,6414 OMRG16407 August 1994	
0013	128	Operation and Service Manual Series 300,4039,4045,6068 Marine Engines OMRG20144 February 1995	
0014	120	Operators Manual 6076 Marine Engines OMRG20145 March 1992	
0015	32	Operators Manual 6076 AFD OEM OMRG21029 December 1991	






0016	114	Operators Manual 6076 Natural Gas Engines OMRG21881 February 1993	
0017	78	Operators Manual Series 220 OEM 3009,3011,3014,4019 OMRG21891 February 1993	
0018	128	Operation and Service Manual 6076 AFM 30 Marine Diesel Engine OMRG23321 May 1994	
0019	102	Operators Manual PowerTech 8.1L 6081 Natural Gas Engines OMRG23552 December 2002	
0020	178	Operators Manual PowerTech 8.1L 6081 Diesel Engines OMRG24828 August 2004	







0021	164	Operators Manual PowerTech 4.5L and 6.8 L OMRG25204 November 2006	
0022	136	Operation and Service Manual Series 500 – 6076 OEM OMRG25412 March 1997	
0023	124	Operation and Service Manual Series 400 – 6076 OEM OMRG25413 March 1997	
0024	136	Operation and Service Manual Series 500 – 6101 OEM OMRG25414 November 1996	
0025	144	Operation and Service Manual PowerTech 10.5L & 12.5L 6105 and 6125 OEM OMRG25752 June 1997	






0026	108	Operators Manual PowerTech OEM 0.9,1.1,1.2,1.5,2.0L 3009,3011,3012,3015,4020 OMRG26439 March 2004	
0027	94	Operation and Service Manual PowerTech 6.8 L & 6068 Compressed Natural Gas OMRG27896 September 1998	
0028	164	Operators Manual PowerTech 2.9 L OEM OMRG27897 June 2006	
0029	180	Operators Manual PowerTech 12.5 L 8125 Marine Diesel OMRG28994 January 2003	
0030	145	Operation and Service Manual PowerTech 8.1 L & 6081 Marine Diesel OMRG28995 April 2000	







0031	191	Operators Manual PowerTech 4.5 L & 6.8 L 4045 & 6068 Marine Diesel OMRG28997 March 2002	
0032	250	Operators Manual PowerTech 4.5 L & 6.8 L 4045 & 6068 OEM OMRG33324 August 2006	
0033	218	Operators Manual 10.5 L & 12.5L 6105 & 6125 OEM OMRG29968 March 2006	
0034	106	Operators Manual 8.1 L 6081 HFN04 Natural Gas OMRG33363 May 2005	
0035	118	Operators Manual PowerTech 2.4L & 3.0L 4024 and 5030 OEM OMRG34851 October 2004	
0036	230	Operators Manual PowerTech 8.1L 6081HF070 OEM OMRG34944 March 2006	






0037	232	Operators Manual PowerTech Marine Engines 4045DFM70/TFM75, 6068SF50/75, 6068TFM75/76 OMRG35856 October 2007	
0038	190	Operators Manual PowerTech 6081 AFM 75 Marine Engines OMRG35860 May 2006	
0039	200	Operators Manual PowerTech 6125 AFM 75 6125 SFM 75 Marine Engines OMRG35863 October 2007	
0040	108	Operators Manual PowerTech OEM 1.3 & 1.6 L 3013DF270,3013DF271 3016DF270,3016DF271 OMRG36330 June 2004	






0041	190	Operators Manual PowerTech Plus OEM 4.5 & 6.8 L 4045HF485,6068HF485 OMRG36852 February 2006	
0042	196	Operators Manual PowerTech Plus OEM 9.0 L 6090HF485 OMRG36864 October 2006	
0043	206	Operators Manual PowerTech Plus OEM 13.5 L 6135HF485 OMRG36873 March 2008	
0044	180	Operators Manual PowerTech OEM 4.5 & 6.8 L ,4045 & 6068 OMRG37407 April 2008	
0045	94	Parts Manual PowerTech 6.8 L , 6068 OEM PC2522 February 2001	





0046	577	Service Manuals Series 400,6466 Diesel CTM1, October 1994	<p>Series 400 5455 Diesel Engines</p> <p>Deere Power Systems Group CTM 1 (10/94) 1994</p>
0047	547	Component Technical Manual Series 300, 3179,4239,6359,4276,6414 CTM4 October 1995	<p>Series 300 3179, 4239, 6359, 4276, and 6414 Diesel Engines</p> <p>COMPONENT TECHNICAL MANUAL</p>  <p>Deere Power Systems Group CTM 4 (10/95) 1995</p> 
0048	437	Component Technical Manual 6076 Engines CTM6 October 1991	<p>6076 Engines Serial Number 1 - 199999</p> <p>COMPONENT TECHNICAL MANUAL</p>  <p>Deere Power Systems Group CTM 6 (10/91) 1991</p> 
0049	682	Component Technical Manual Series 300, 3029,4039,4045,4276,6414 CTM4 October 1995	<p>Series 300 3029 (-499999), 4039, 4045, 6059 and 6068 Diesel Engines</p> <p>COMPONENT TECHNICAL MANUAL</p>  <p>Deere Power Systems Group CTM 4 (10/95) 1995</p> 
0050	450	Component Technical Manual Series 500, 6619 CTM9 January 1996	<p>Series 500 6619 Diesel Engines</p> <p>COMPONENT TECHNICAL MANUAL Series 500-6619 Diesel Engines</p> <p>CTM 9 (1/96) Single</p> <p>Deere Power Systems Group CTM 9 (1/96) 1996</p>






0051	422	Component Technical Manual Series 500, 6101 CTM20 November 1995	
0052	455	Component Technical Manual Series 400, 6076 CTM42 March 1995	
0053	455	Component Technical Manual 6101 CTM61 May 1993	
0054	448	Technical Manual Oem Engine Accessories CTM67 December 2005	
0055	262	Component Technical Manual Electronic Fuel Injection Systems CTM68 November 2001	






0056	664	Technical Manual Alternators and Starter Motors CTM77 July 2005	
0057	377	Component Technical Manual 6076 Natural Gas Engines CTM82 June 1993	
0058	506	Technical Manual PowerTech 8.1 L Base Engine CTM86 July 2006	
0059	462	Technical Manual PowerTech 6081 Natural Gas Engines CTM87 May 2004	
0060	450	Technical Manual PowerTech 10.5 L & 12.5 L Engines CTM100 November 2006	
0061	748	Technical Manual PowerTech 4.5 L & 6.8 L Engines CTM104 May 2006	

0062	400	Operation and Diagnostics PowerTech 6.8 & 8.1 L Gas Engines CTM 113 December 2000	
0063	332	Technical Manual PowerTech 10.5L & 12.5 L CTM115 July 2004	
0064	540	Technical Manual PowerTech 0.9,1.1,1.2,1.3,1.5,1.6,2.0L Yanmar 4TNE98 CTM119 June 2004	
0065	344	Component Technical Manual PowerTech 2.9 L Engines CTM125 January 2001	
0066	593	Component Technical Manual PowerTech 6.8 L & 8.1 L Diesel CTM134 May 2003	

0067	384	Component Technical Manual PowerTech 6.8 L & 6068 Gas Engine CTM146 October 1998	
0068	661	Component Technical Manual PowerTech 4.5 & 6.8 L Diesel CTM170 May 2003	
0069	646	Technical Manual PowerTech 10.5L & 12.5 L CTM188 July 2004	
0070	312	Technical Manual PowerTech 4.5 L & 6.8 L Diesel CTM207 August 2004	
0071	676	Technical Manual PowerTech 4.5 L & 6.8 L Diesel CTM220 January 2004	

0072	193	Technical Manual PowerTech 8.1L Mechanical Fuel Systems CTM243 May 2003	
0073	790	Technical Manual PowerTech 8.1L Electronic Fuel Systems	
0074	319	Component Technical Manual -PowerTech 4.5L & 6.8 L Electronic Fuel Systems CTM284 May 2003	
0075	824	Technical Manual PowerTech –Natural Gas 8.1L Electronic Fuel Systems	
0076	426	Component Technical Manual -PowerTech 24 L & 30 L CTM301 September 2006	

0077	1442	Technical Manual PowerTech 4.5 L & 6.8 L Electronic Fuel Systems CTM320 August 2007	
0078	550	Technical Manual PowerTech 4.5 L & 6.8 L Electronic Fuel Systems CTM331 April 2006	
0079	1352	Component Technical Manual-PowerTech Plus 13.5 L Electronic Fuel Systems CTM370 July 2007	
0080	1346	Technical Manual PowerTech Plus 9.0 L Electronic Fuel Systems CTM385 July 2007	
0081	436	Technical Manual PowerTech Plus 9.0 L OEM CTM400 May 2007	

<p>0082</p>	<p>464</p>	<p>Technical Manual PowerTech 13.5 L OEM CTM415 July 2007</p>	
<p>0083</p>	<p>972</p>	<p>Technical Manual PowerTech 4.5 L & 6.8 L CTM502 August 2007</p>	
<p>0084</p>	<p>504</p>	<p>Technical Manual PowerTech 8.1 L OEM CTM861 July 2006</p>	
<p>0085</p>	<p>742</p>	<p>Technical Manual PowerTech 4.6 L & 6.8 L OEM CTM1041 January 2006</p>	
<p>0086</p>	<p>862</p>	<p>Technical Manual PowerTech 6.8 L OEM CTM3201 January 2006</p>	

0087	634	Component Technical Manual 13.5 L Diesel CTM3701 January 2006	
-------------	------------	--	--